

How to transfer a call on a Fanvil/Linkvil Wi-Fi/Cordless phone

Attended Transfer

1. While on a call, press the "**Xfer**" soft key
2. **Dial** the extension or phone number: Enter the number or extension of the person or department you want to transfer the call to.
3. Wait for the person to answer: Once they pick up, you can speak to them to let them know you're transferring the call (optional).
4. Press the "**Xfer**" soft key again: This completes the transfer and connects the caller to the new party.

Blind Transfer

1. When you are on the call, press the '**More**' soft key, and then '**Xfer**'.
2. For a blind transfer, please type in the number you wish to forward this phone call to and then press '**More**' and '**Xfer**' for the second time.
3. Hang up the phone after successful transfer completion message.